

JEWELRY MAKING USER GUIDE

www.moddahobbykits.com

WARNING

- This kit contains small parts and sharp tools.
 Keep away from children
- Activity recommended for Adults and Teenagers 12+

Warnings for Cutting Tools

- Please keep out of children.
- Always keep points away from fingers and body. Handle with care. Use with adult supervision.
- Please do not use to cut hard material and steel wire, etc.
- Products have functional sharp points. Contact may result in injury.
- Please use safety items, such as safety glasses and protective gloves.

The Kit Contains







Making Your First Single Drop Earrings

Materials

- 4 in 1 pliers
- Beads

- 2 Headpins
- 2 Earwires



1- String your beads onto the head pin, starting with the bottom bead and ending at the top



2- Bend the wire at a 90 degree angle with your 4 in 1 pliers



3- Leave about 3/8" (1cm) tail



4- Cut the head pin with your flat nose pliers



5- Grasp the end of the wire with your 4 in 1 pliers



6- Rotate your pliers slightly by turning your wrist clockwise, until it forms a complete loop



7- Open up the loop with your 4 in 1 pliers, gently twisting the loop up



8- Take the earwire and thread the loop of the earwire through the open loop



9- Close the open hook using your pliers. Make it nice and tight so the earrings won't fall apart. And your first earrings are ready!

Making Your First Bracelet With Elastic Cord

Materials

- 4 in 1 Pliers
- Elastic nylon cord

Beads



1- Select your beads and decide on a design before putting the beads on the elastic cord



2- Measure your elastic cord: Take the elastic cord and wrap it one and a half times around your wrist.Cut it with your pliers



3- Start threading your heads



4- Check the length of bracelet before making the knot. The first and last bead should be touching. If you see any cord or gaps, you will need more beads



5- Make a couple of surgeon's knots or a couple overhand knots in your elastic cord, being careful not to pull too tightly. Then slide the knot under the bead



6- Your bracelet is readu!

Making Your First Wire Wrapped Bracelet and Necklace

Materials

- 4 in 1 pliers
- 2 Crimp beads
- Beads

- 1 Jump ring
- 1 Lobster clasp
- Beading wire



1- First select your beads and arrange the pattern you want



2- Measure your beading wire around your wrist or neck, then add 4-5 inches



3- Cut the beading wire with your 4 in 1 pliers



4- Thread one crimp bead and one lobster clasp



5- Slip the wire through the clasp loop and bring the end of the wire back through the crimp bead



6- Take your 4 in 1 pliers, simply grasp the crimp bead and squeeze gently and pull to be sure it is secure



7- Now start threading your beads according to your pattern until you reach other end. Be sure leave about 3-4 inches of the wire at the end



8- To hide the end of the wire, thread it back through some of the beads. or cut the excess with your 4 in 1 pliers



9- Tight all of your beads by pulling on the tail end of the loose wire and then check the fit of the necklace / bracelet. Add beads if necessary



10- Thread one crimp bead, then thread the jump ring



11- Slip the wire through the jump ring loop and bring the end of the wire back through the crimp bead



12- Hide the excess wire into the next beads



13- Take your 4 in 1 pliers, simply grasp the crimp bead with the flat section of your pliers and squeeze gently and pull to be sure it is secure



14- Use your pliers to trim off excess wire



15- That's it, your necklace/bracelet is ready

Making Your Natural Stone Ring

Materials

- 4 in 1 Pliers
 - Ring Wire

Beads



1- Measure the size you want



2- Thread the wire through the crystal



3- Wrap the wire through the ring center several times



4- Move the crystal to the center and fix it



5- Cut the extra wire with your 4 in 1 pliers



6- You have your first natural stone ring!









Don't Forget to Add
Photos of Your First
Jewelry to Your Review
on Amazon!